

Low Risk Alginate Impressions

- 1.) Select a proper fitting rigid impression tray (see examples).
- 2.) Fluff the powder and clean and dry the bowl.
- 3.) Using cool water, measure out the powder and liquid according to the manufacturer's instructions.
- 4.) Spatulate thoroughly, load the tray, and place it in the patients mouth.
- 5.) Remove it from the mouth and wrap it in a damp paper towel until it can be poured.
- 6.) Pour the impression within the time frame designated in the instructions.